

FILE: STP-0.1-12b
REV: 01.11.06

LANDING SCHEDULE		
TREAD LENGTH (T)	LANDING PLANK LENGTH (LP)	LANDING WIDTH OUTSIDE DIM. (LW)
36"	LP=T+S+ 1/2Y	LW=2(LP)+**
38"		
40"		
42"		
44"		
46"		
48"		

- ** ALL ITEMS HAVE STANDARD MAUFACTURING TOLERANCES.
- * ALLOW 1/8" TOLERANCE BETWEEN LANDING PLANKS.
- Y = SPACE BETWEEN STRINGERS.
- S = STRINGERS

EXAMPLE:

T=36", S=3", & Y=6"

THEN:

LP=36+3+1/2(6)=42"
LP=42"+**

LW=2(42)+**
LW=84"+**

180° LANDING

SCALE: N.T.S.
FILE: STP-0.1-12b